

Accessories

P P.0

All you need to make testing faster and simpler.

PAT ADAPTER 1

Makes a PAT tester out of your multifunction or insulation / continuity tester. For PAT documentation use PATLOG3.





KEWCHECK R2

For fast and secure testing of ring mains.

LIGHTMATE KIT

For faster, safer testing at light fittings. Pouch contains fittings for BC, ES, GU10, SES, SBC.

KEWTECH



KEWTK1

Kit includes

- Lightmate Kit
- PAT Adapter 1
- Kewstick UNO
- JUMPLD 1
- Kewcheck R2
- Kewlok & Labels



KEWLOK

Locking out device fits most toggle MCBs and mains switches - saves on multiple kits.

Includes warning labels.



KEWCHECK R2 FL

Just attach your own connector for any system.





Go to **kewtechcorp.com** for full specifications