

Switches

1 Way Switches

MCP010	10AX 1 Gang 1 Way Plate Switch - Grey
MCP010PW	10AX 1 Gang 1 Way Plate Switch - Polar White



2 Way Switches

MCP011	10AX 1 Gang 2 Way Plate Switch - Grey
MCP011PW	10AX 1 Gang 2 Way Plate Switch - Polar White

MCP012	10AX 2 Gang 2 Way Plate Switch - Grey
MCP012PW	10AX 2 Gang 2 Way Plate Switch - Polar White

MCP013	10AX 3 Gang 2 Way Plate Switch - Grey
MCP013PW	10AX 3 Gang 2 Way Plate Switch - Polar White

MCP019	10AX 4 Gang 2 Way Plate Switch - Grey
MCP019PW	10AX 4 Gang 2 Way Plate Switch - Polar White

MCP105	10AX 6 Gang 2 Way Plate Switch - Grey
MCP105PW	10AX 6 Gang 2 Way Plate Switch - Polar White



Intermediate Switches

MCP025	10AX 1 Gang Intermediate Plate Switch - Grey
MCP025PW	10AX 1 Gang Intermediate Plate Switch - Polar White

