## info@gaplighting.co.uk

+44 1322 620 100

www.gaplighting.co.uk

TECHNICAL DATA SMART SYNC CONTROL

PRODUCT CODE

T-4Z-WALL-B

## SMART SYNC





## PRODUCT DESCRIPTION

RGB+CCT 4 Zone Touch Controller with smooth dimming function and dynamic multi colour changing programmes. For wall mounting anywhere - battery powered. Incorporating wireless RF 2.4G technology. Synchronise multiple products simultaneously or control independently up to 30m range.







To see all compatible products go to www.gaplighting.co.uk

WARRANTY

3 years guarantee

@GAPLightingLtd

GAP Lighting Ltd

/GAPLightingLtd

GAP Lighting Ltd

9

in

## PRODUCT FEATURES

RF 2.4G remote control for Smart Sync products

RGB colour bar for manual colour selection

CCT bar for manual white selection

Brightness control bar | 9 dynamic modes

Speed control buttons for dynamic modes

Range up to 30m

Pair any number of Smart Sync luminaires within 30m range (without obstruction) for synchronised control

Back plate for easy surface mounting / removal



PRODUCT DATA

Model	T-4Z-WALL-B
Control	4 zone RGB+CCT remote with touch dimming control
Function	Dimming   speed variation   dynamic colour changing modes   CCT tuneable white   single colour settings   master control function   60s delay off
Frequency	2.4GHz high frequency wireless
Remote distance	up to 30 metres
Dimensions	L 80mm   W 80mm   D 19mm
Material	Glass surface   Plastic housing
Working temp.	-20 to + 60°C
Power	2 x AAA batteries  Standby 15uA
Approvals	CE   ROHS

**Sync**: Switch on via the mains switch. Within 3 seconds, select a Zone-ON button and hold down. Pairing is confirmed when the fitting flashes green. If it does not flash green, try the procedure again.

**Unsync:** Switch on via the mains switch. Within 3 seconds, select the Zone-ON button that relates to the zone you wish to unsync and hold down. Unsyncing is confirmed when the fitting flashes red. If it does not flash red, try the procedure again.

You can go through the different dynamic modes by pressing **'M'** and adjust the speed by pressing **'S+/S-'**. Hold the Zone-ON button to select the colour white. Select **'S+/S-'** to saturate the solid colours when using the colour wheel. If you are using RGB+CCT products press the **white bar** to change the colour temperature.