

Microwave Movement Sensor

• This product is fitted with a microwave movement sensor. Please see below detailed operating instructions.

Technical Specifications:

Operating voltage	220 ~ 240 VAC 50/60Hz	
Rated load	400W (Capacitive load) 800W (Resistive load)	
Stand-by power	<0.5W	
Sensitivity	10% / 50% / 75% / 100%	
Hold-time	5s / 90s / 5min / 15min	
Daylight sensor	2lux / 10lux / 50lux, disable	
Microwave frequency	5.8 GHz +/- 75MHz	
Transmitting power	<0.2mW	
Detection range	maximum (diameter x height): 10m x 6m	
Detection angle	30°~150°	
Working temperature	-20°C ~ 60°C	





Instruction leaflet

Forca EM, MW & CCT LED Bulkhead 77902



Settings:

1. Sensitivity	2. Hold-time	3. Daylight sensor
Sensitivity can be adjusted by selecting	Hold-time refers to the time period that	Different daylight threshold can be preset on
the combination on the DIP switches for	the light remains 100% on if no more	DIP switches. Light will always turn on upon
different applications.	movement is detected.	movement if daylight sensor is disabled.
$ \begin{array}{c c} I - 100\% \\ II - 75\% \\ III - 50\% \\ IV - 10\% \end{array} \stackrel{\bullet}{\overset{\bullet}{\circ}} \begin{array}{c} 1 & 2 \\ I & \bullet & 100\% \\ III & \circ & 75\% \\ III & \circ & 50\% \\ IV & 0 & 10\% \end{array} $	$ \begin{array}{c c} I-5s\\ II-90s\\ III-5min\\ IV-15min \end{array} \stackrel{\bullet}{\stackrel{\bullet}{\rightarrow}} \begin{array}{c c} 3 & 4\\ I & \bullet & 5s\\ II & \bullet & 90s\\ III & \bullet & 5min\\ IV & 0 & 15min \end{array} $	$ \begin{array}{c c} I - Disable \\ II - 50Lux \\ III - 10Lux \\ IV - 2Lux \end{array} \stackrel{\bullet}{\stackrel{\bullet}{\rightarrow}} \begin{array}{c} 5 & 6 \\ \hline I & \bullet & Disable \\ III & \circ & 50Lux \\ IIII & \circ & 10Lux \\ IV & \circ & 2Lux \end{array} $

Trouble shooting:

Malfunction Cause Remedy	Cause	Remedy
	Incorrect light-control setting selected	Adjust daylight threshold setting
The light will not come on	Faulty lamp	Replace lamp
	No power supply	Check power to sensor
The lamp is always on	Continuous movement in the detection zone	Check detection area setting
T	The sensor is not mounted for reliably detecting movement	Securely mount enclosure
The lamp is on without any identifiable movement	Movement occurred, but not identified by the sensor (Movement behind wall, movement of small object in immediate lamp vicinity etc.)	 Reduce sensitivity. Check the movement behind walls to avoid facilities such as water pipe, fan, which may mis-trigger the sensor.
The lamp will not work despite movement	Rapid movements are being suppressed to minimize malfunctioning or the detection radius is too small.	Check detection area setting

Care and Safety

• We recommend cleaning with a soft dry cloth. Do not use solvents or abrasive cleaners as these could damage the finish.

• For your safety, always switch off the power supply before cleaning.

CE

www.saxbylighting.com

V3 14/02/2020



Thank you for purchasing this light fitting. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product. Please retain these instructions for future reference.

Warning

This product is Class 2 (Double insulated) and must not be earthed.

Please read these instructions carefully before commencing any work.

This unit must be fitted by a competent and gualified electrician.

Install in accordance with IEE Wiring regulations and current Building Regulations.

To prevent electrocution switch off at mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge. If you are in any doubt, please consult a qualified electrician.

This light fitting should be connected to a circuit with a 30mA RCD fitted.

If replacing an existing fitting, make a careful note of the connections.

This product contains non-replaceable parts and cannot be serviced. If damage occurs the part should be scrapped.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

Technical data

Supply Voltage:	240V~, 50 Hz	Lumens: 120Im in EM mode Duration: 3 hours (180 Minutes)	Change over time: Approximately 1s Battery Specification: LifePO4 3.2V 1500mAh
Bulb Type:	18W LED module - 3000K/4200K/6500K	Operating Temperature: 0°C - 50°C Maximum Operating Humdity: 90%	Battery Charge Time: 24 Hours Battery warranty: 2 years
CE	Conformity with all relevant EC Directive requireme	nts.	
X	Waste electrical products should not be disposed of Please recycle where facilities exist. Check with you local store for recycling advice.		
	The power supply is Double Insulated and does not	t require connection to an Earth ci	rcuit.
\bigotimes	This product is not suitable for dimming.		
IP65	This product is rated at IP65.		

Layout

- Plan the desired layout of this fitting carefully, ensuring the cables will reach the distance between the junction box and the light fitting.
- · Avoid locating any cables in positions that would cause a hazard. Position cables and junction boxes (not supplied) away from areas where they may be at risk from being cut, trapped or damaged.
- · The mains supply cable must have a minimum cross sectional area of 1.0mm².
- · Cables must be protected using suitable conduit or plastic trunking.
- · The products can be wall or ceiling mounted. If wall mounting ensure that the power supply is at the bottom.

Individual casings

The following individual casings are available for purchase separately.

77904 : White plain 77907 : Grey plain 77910 : Black plain 77905 : White eyelid 77908 : Grey eyelid 77911 : Black eyelid 77906 : White grill 77909 : Grey grill 77912 : Black grill

77913 : Chrome plain

Installation

Existing fittings must be completely removed before installation of a new product. Before removing the existing fitting, carefully note the position of each set of wires.


- Remove the 4 fixing screws and detach the shade. Keep safe for refitting later.
- a joist at the point of fixing to support the weight of the product.
- Knock out the chosen fixing holes.
- · Fix into position. Take care to avoid damaging any concealed wiring and pipes. The correct fixings should be used for brick, cavity walls or plasterboard.
- · Pierce a hole in the grommet, and pull the cable through.
- · Wire as detailed below.

Wirina

- This product is double insulated and must not be earthed. If there are any incoming e with good quality insulation tape. This is to ensure earth continuity throughout your
- · Having correctly identified the wiring from your existing light fitting, connect to the gu supplied link cables where necessary.



Maintained (Unswitched) Wiring: The product is on permanently and comes on during a power failure



Check that...

- · You have correctly identified the wires.
- · The connections are tight.
- No loose strands have been left out of the connection block

Commissioning

- Ensure that the screws and cable entry points are sealed to maintain the IP rating of the product.
- Refit the shade, ensuring that the seals are correctly located.
- · Gently push your chosen casing onto the shade until it clips in place.
- Replace fuse or circuit breaker and switch on. Your light is now ready for use.

Fitting/replacing bulbs

This system contains non-replaceable parts and cannot be serviced. If damage occurs the part should be scrapped.

CCT Function

 This colour is changeable between 3000K-4200K-6500K, using the switch inside the product.

Α	WARM WHITE	3000K
B	COOL WHITE	4200K
C	DAYLIGHT WHITE	6500K

Hold the product in place and mark the position of the holes. Ensure the wall is capable of holding the weight of the product, or if fitting to a ceiling, ensure there is

h cables, they must be joined together a perty.	nd well insulated
k fit connection block in the following wa	ay, using the
Non-Maintained Wiring: The product is and comes on during a power failure	s normally off
SUPPLY	LIGHT FITTING
PERMANENT LIVE	BROWN (L)
NEUTRAL	BLUE (N)
Maintained (Switched) Wiring: The pro light - switch on/off, light turns on/off. Comes on during a power failure.	duct is used as a normal
light - switch on/off, light turns on/off. Comes on during a power failure.	
light - switch on/off, light turns on/off. Comes on during a power failure.	